

3.5 Easy Lock – magnetic door retainer



Attention: Risk of accident when manoeuvring with doors open.
Reduce speed to a maximum of walking speed!



Attention: Do not keep your finger between the handle and the door when pressing the lever,
danger of crushing when releasing the magnet from the stop plate.

Cleaning: see cleaning instructions under 3.4 Maintenance of stainless steel fittings

Operating instructions for unlocking the magnetism can be found on the sticker "Short information for operation and maintenance" on the inside right-hand side of the door and must be strictly observed!

Magnetischer Türfeststeller Easy Lock:

Sichert selbsttätig, zum
Lösen Hebel drücken!



Magnetic door retainer Easy Lock:

Easily secured,
press handle to release