

6.5 Emergency release and central locking system

The vehicle may be equipped with an emergency release in combination with central locking to allow a person accidentally trapped in the load compartment to open the door from the inside.



Emergency release only releases the espagnolette lock, not the lock!
The central locking system must therefore be released before the emergency release is actuated.

The marking of the emergency release according to the operating instructions point 6.4 must be observed!

If an additional central locking system is installed in the body, it can be unlocked from inside by pressing the green button.

After opening the central locking system, it is possible to open the emergency release (item 6.4)

Bedienungsanleitung
Laderaum - Notentriegelung
mit Zentralverriegelung

Über die Notentriegelung kann der Drehstangenverschluss von innen geöffnet werden, um das Öffnen der Türe von innen zu ermöglichen.

Hierfür muss zunächst die Zentralverriegelung entriegelt werden.

1. Zentralverriegelung

Grünen Taster drücken um die Zentralverriegelung zu öffnen.




2. Notentriegelung

Push Button an der Innenseite der Hecktüre kräftig drücken und die Laderaumtüre von innen aufstoßen




Kiesling Fahrzeugbau GmbH
D- 89160 Dornstadt-Tomerdingen
Tel.: +49.7348.2002-0
info@kiesling.de

Kiesling
www.kiesling.de

Sticker attached to the inside of the rear door.